

| BOMCO F-1300/F-1600-- Mud pump Parts Manual-1 | | |
|--|--|-----------------|
| Item no. | Name | Part no. |
| 1 | F-1300 general assembly drawing | AH13010200 |
| 2 | F-1600 general assembly drawing | AH16010200 |
| 3 | F-1300 crankshaft assembly | AH1301020200 |
| 4 | F-1600 crankshaft assembly | AH1601020100 |
| 5 | F-1300 pinion shaft assembly | AH1301020300 |
| 6 | F-1600 pinion shaft assembly | AH1601020200 |
| 7 | F-1300/1600 crosshead assembly | AH1301020400 |
| 8 | F-1300/1600 fluid end assembly | AH1301020500 |
| 9 | F-1300/1600 power end lubrication assembly | AH1301020600 |
| 10 | F-1300/1600 spray pump assembly | AH1301020800 |
| 11 | F-1300/1600 suction desurger assembly | AH0000050100 |
| 12 | F-1300/1600 discharge filter assembly | |
| 13 | KB-75 pulsation dampener | AK75350200 |
| 14 | Pulsation dampener pneumatic hose assembly | AH100102130100 |
| 15 | JA-3 Shear safety valve | AH0000060200 |
| 16 | F-1300/1600 attachment spare parts | |
| 17 | F-1300/1600 attachment tool | |